

SELECTOR ($S_{1a \sim i}$)

1. PHONO₁
2. PHONO₂
3. AM MONO
4. FM MONO
5. FM AUTO
6. AUX

MODE

S_2 1. STEREO S_3 1. NORMAL
2. MONO 2. REVERB

TAPE MONITOR (S_4)

1. OFF
2. ON

LOUDNESS (S_5)

1. OFF
2. ON

MUTING (S_6)

1. ON
2. OFF

NOISE CANCELER (S_7)

1. OFF
2. ON

HIGH FILTER (S_8)

1. OFF
2. ON

LOW FILTER (S_9)





1. OFF
2. ON

SPEAKER SELECTOR (S_{10})


1. OFF
2. SYSTEM A
3. " B
4. " A+B

ANTENNA (S_{11})









1. LOCAL
2. DISTANT



UL and LA APPROVED SET
CONNECTION OF POWER SUPPLY
CIRCUIT




VOLTAGE ADJUSTMENT



✕ WIRED-IN FUSE

☐ CSA APPROVED EQUIPMENT ONLY



T001
400-5338

