



- SLIDE SWITCHES**
- S1 STEREO FM AFC
 - S2 STEREO (1-ON → 2-OFF)
 - S3 LOUNDSNESS (1-ON → 2-OFF)
 - S4 IMPEDANCE SELECTOR (1-80 → 2-160)
 - S5 SPEAKER (1-ON → 2-OFF)
 - S6 TAPE MONITOR SWITCH
 - S7 POWER (1-ON → 2-OFF)
 - S8 AM BAND (1-LW → 2-LMW)
 - S9 IF TRAP (1-OFF → 2-ON)
 - S10 VOLUME SELECT (1-15V → 2-230V)

- SELECTOR**
- 1 STEREO FM AFC
 - 2 FM
 - 3 FM AFC
 - 4 AM
 - 5 PHONO
 - 6 AUX

- ITEM NO.**
- VR1 TREBLE
 - VR2 BASS
 - VR3 VOLUME
 - VR4 BALANCE
 - VR5 FM MPX SEPARATION
 - VR6 FM MPX INDICATOR
 - VR7 FM MPX INDICATOR ADJUSTMENT

- PACKAGING**
- FRONT SECTION
 - MPX SECTION
 - REAR SECTION
 - CONTROL SECTION

- SECTION**
- C100 - C110
 - R100 - R110
 - R120 - R130
 - R140 - R150

- ITEM NO.**
- VR1 TREBLE
 - VR2 BASS
 - VR3 VOLUME
 - VR4 BALANCE
 - VR5 FM MPX SEPARATION
 - VR6 FM MPX INDICATOR
 - VR7 FM MPX INDICATOR ADJUSTMENT

- SECTION**
- C100 - C110
 - R100 - R110
 - R120 - R130
 - R140 - R150

- ITEM NO.**
- VR1 TREBLE
 - VR2 BASS
 - VR3 VOLUME
 - VR4 BALANCE
 - VR5 FM MPX SEPARATION
 - VR6 FM MPX INDICATOR
 - VR7 FM MPX INDICATOR ADJUSTMENT

- SECTION**
- C100 - C110
 - R100 - R110
 - R120 - R130
 - R140 - R150

ALL VOLTAGES ARE MEASURED WITH V.T.T. & MEASURED WITH PRECISION CURRENT METER

--- D.C. VOLTAGE (NO SIGNAL INPUT)

V --- R.I.P.P.L.E. VOLTAGE

(V) --- D.C. CURRENT

(V) --- D.C. SIGNAL INPUT

INPUT VOLTAGE TO TRANSFORMERS

OUT PUT (DC)

DC VOLTAGE (AT 0 WATTS OUT PUT)

ITEM NO.	SECTION	ITEM NO.	SECTION
VR1	TREBLE	VR6	FM MPX INDICATOR
VR2	BASS	VR7	FM MPX INDICATOR ADJUSTMENT
VR3	VOLUME		
VR4	BALANCE		
VR5	FM MPX SEPARATION		
C100 - C110	CONTROL SECTION		
R100 - R110	FRONT SECTION		
R120 - R130	MPX SECTION		
R140 - R150	REAR SECTION		